

WOODEN FURNITURE CARE

Congratulations on your purchase! Now, you can sit back and enjoy your outdoor furniture for years to come.

All Wood products need care to keep it looking good and to prevent premature weathering and deterioration.

It is highly suggested to put the painted furniture on a covered porch, patio or in a shady area for longevity. Dust with a soft cloth, clean with water, soft brush and air dry.

Due to the nature of wood, surface cracking and slight color variations will occur. The wood and the product will remain structurally sound for years.

WOODEN KIDDIE ROCKER SERIES 4215 ASSEMBLY INSTRUCTIONS



- CAUTION-PLEASE READ
- 1. This chair is NOT RECOMMENDED FOR WEIGHT OF MORE THAN 500LBS.
 - 2. Care should be taken to avoid tipping while seated.
 - 3. This chair is designed for use on level ground only. Do not use on unlevel ground.
 - 4. To avoid harm or injury-do not sit on arms.
 - 5.PRODUCT IS FOR RESIDENTIAL USE ONLY-NOT MEANT FOR COMMERCIAL USE.

PACKAGE CONTENTS CONTENIDO DEL PAQUETE. CONTENU DE L'EMBALLAGE. CONTENIDO DEL PAQUETE

