

## How To Assemble Your Garden Bridge

**TOOLS NEEDED:** Philips screwdriver, power drill optional

**CAUTION:** When assembling bridge, **DO NOT** completely tighten the bolts and nuts until all the parts & holes are properly aligned.

### HARDWARE INCLUDED:

111 PCS 1.38" Long  
Wood Screw



4 PCS 1" Short  
Wood Screw



4 PCS  
4" Long Machine  
Thread & 4 PCS Nuts



2 PCS  
1.75" Short Machine  
Thread & 2 PCS Nuts



### PARTS INCLUDED:

**A1**

1 PC



**A2**

1 PC



**C1**

1 PC



**C2**

1 PC



**B**

1 PC



**D**

1 PC



**E1**

1 PC



**E2**

1 PC



**F**

3 PCS





**G**

20 PCS



AS CEDAR WOOD AGES NATURALLY, ITS RUSTIC CHARACTER WILL BE ENHANCED. DUE TO THE NATURE OF WOOD, SURFACE CRACKING AND SLIGHT COLOR VARIATIONS WILL OCCUR. THE WOOD AND PRODUCT WILL REMAIN STRUCTURALLY SOUND FOR YEARS.

# ASSEMBLY DIAGRAM:



**Step 1:** Connect (A1) to (A2) by overlapping the pieces and matching to the center hole. Then attach side (B) rail using 3pcs of 4" Long Machine Thread + Nuts.

**Step 2:** Connect (C1) to (C2) by overlapping the pieces and matching to the center hole. Then attach side (D) rail using 3pcs of 4" Long Machine Thread + Nuts.

**Step 3:** Connect (E1) to (E2) by overlapping the pieces matching to the center holes using 2pcs of 1.75" Short Machine Thread + Nuts. This is the center frame of the bridge.

**Step 4:** Placing the slats: locate 3 of the shortest (F) slats and place them horizontally in between the rail posts. Then, place the remaining 20 longer slats (G) onto the bridge and space evenly.

**Step 5:** Begin to screw 5pcs of 1.38" Long Wood Screws per slat. Starting from the center of the bridge out.

**Step 6:** When you reach the very last end slats (at each end), use 2pcs of 1" Short Wood Screws at each end corner. Because the bridge has a natural slant/curve, it requires a shorter screw.